

SIZES AND SPECIFICATIONS

		ROUND TAPERED								ROUND NON-TAPERED								SQUARE TAPERED				SQUARE NON-TAPERED							
NOMINAL COLUMN SIZES		6"	8"	10"	12"	14"	16"	18"	20"	24"	8"	10"	12"	14"	16"	18"	20"	24"	9"	10"	12"	16"	6"	8"	10"	12"	14"		
Total Height (Including caps & bases)	5'																		✓	■	■	■							
	6'	✓	✓	✓	✓		✓		✓											✓	■	■							
	8'	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓			✓	■	✓	✓	■+	✓	■	✓	
	9'		✓	✓	✓	✓	✓	✓						✓	✓	✓	✓						✓	✓	■+	✓	■	✓	
	10'		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓							✓	■+	✓	■	✓
	12'			✓	✓	✓	✓	✓	✓	✓	✓	✓	✓				✓								✓	✓	✓		
	14'				✓	✓	✓	✓	✓	✓		✓	✓				✓										✓		
	16'				✓	✓	✓	✓	✓	✓		✓	✓														✓		
	18'					✓	✓	✓	✓	✓																			
	20'					✓	✓	✓	✓	✓																			
	22'									✓	✓																		
	24'							✓	✓	✓																			
Top Shaft - Outside Dia./Width		5 ¹ / ₄	6 ¹ / ₈	8	9 ³ / ₈	12	13 ³ / ₄	15 ³ / ₈	16 ³ / ₈	19 ³ / ₄	7 ⁵ / ₈	9 ⁵ / ₈	11 ³ / ₄	13 ³ / ₄	15 ³ / ₄	17 ⁷ / ₈	19 ⁷ / ₈	23 ⁷ / ₈	5 ¹ / ₄	5 ¹ / ₄	8 ¹ / ₂	9	5 ³ / ₄	7 ⁷ / ₈	9 ³ / ₄	11 ³ / ₄	13 ⁷ / ₈		
Bottom Shaft - Outside Dia./Width		5 ³ / ₄	7 ⁵ / ₈	9 ⁵ / ₈	11 ⁷ / ₈	13 ⁷ / ₈	15 ³ / ₄	17 ¹ / ₄	19 ³ / ₄	23 ³ / ₄	7 ⁵ / ₈	9 ⁵ / ₈	11 ³ / ₄	13 ³ / ₄	15 ³ / ₄	17 ⁷ / ₈	19 ⁷ / ₈	23 ⁷ / ₈	8 ¹ / ₂	9 ¹ / ₄	11 ¹ / ₄	16	5 ³ / ₄	7 ⁷ / ₈	9 ³ / ₄	11 ³ / ₄	13 ⁷ / ₈		
Tuscan Cap Width - Foam		8	9 ³ / ₄	12 ¹ / ₄	14 ¹ / ₄	16 ⁵ / ₈	19 ¹ / ₁₆	21 ³ / ₈	24 ³ / ₈	27 ¹ / ₄	9 ³ / ₄	12 ¹ / ₄	14 ¹ / ₄	16 ⁵ / ₈	21 ¹ / ₄	24 ¹ / ₄	28 ³ / ₄	32 ¹ / ₂	8 ³ / ₈	8 ³ / ₈	13 ⁷ / ₁₆		8 ³ / ₈	11 ¹ / ₄	13 ³ / ₄	16 ¹ / ₈	18 ¹ / ₄		
Tuscan Base Width - FRP		8 ¹ / ₈	10 ¹ / ₈	13 ¹ / ₈	15 ¹ / ₂	18 ³ / ₈	21 ¹ / ₄	24	26 ¹ / ₂	32	10 ¹ / ₈	13 ¹ / ₈	15 ¹ / ₂	18 ³ / ₈	21 ¹ / ₄	24	26 ¹ / ₂	32	13 ⁷ / ₁₆	13 ⁷ / ₁₆			8 ¹ / ₈	10 ¹ / ₂	13	14 ⁷ / ₈	17 ⁵ / ₈		
Load Bearing (Roof Loads)		6M	10M	14M	18M	Call	Call	Call	Call	Call	6M	10M	14M	Call	Call	Call	Call	Call	Call	Call	Call	Call	6M	10M	14M	18M	Call		

✓ = Available Plain • = Available Fluted ■ = Recessed Panel M = Thousand + = Raised Panel

Optional: Trimming to length, splitting in half to wrap around existing post.
 Tuscan aluminum bases (see back page).
 Ornamental capitals (see back page).

Dimensions are subject to change without notice.
 Ten (10) year limited warranty if installed according to installation instructions.

Installation Notes: Columns are not primed or painted.
 Caps and bases are hollow and slide around column shaft.
 Fluted, Panel and Recess columns can be trimmed a maximum of 5" for most sizes.

Load capacities are for roof loads only and are reduced if loads are not centered.
 Balconies, floors and & uplift applications require an internal structural support inside.
 Pergolas, trellises and other free standing applications require an internal structural support inside.
 Columns not covered by a roof require flashing at the top of column to prevent water and snow collection.
 Concrete support footings must be below grade. Do not pour concrete or sand inside column shaft.